



RAND  
MCNALLY

# RV TABLET 70



User Manual

## FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications if not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet that is on a different circuit from the GPS unit.
- Consult the dealer or an experienced radio/TV technician for help.

When using the device, ensure that the antenna of the device is at least 20 cm away from all persons.

## IC Compliance Statement

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

## IC Caution

Intentional or unintentional changes or modifications to the equipment not expressly approved by Rand McNally could void the user's authority to operate the equipment.

## IC attestation de conformité

Ce dispositif est conforme à la norme FCC Partie 15 et aux norme(s) RSS permis-exempte(s) d'Industrie Canada. L'opération est soumise aux deux conditions suivantes:

3. Ce dispositif ne peut pas provoquer d'interférence nocive et
4. Ce dispositif doit accepter toute interference reçue, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Attention

Les changements ou modifications à l'équipement, que ce soient intentionnelles ou non, non expressément approuvés par Rand McNally pourraient annuler l'autorisation de l'utilisateur à utiliser cet équipement.

IC: 10199A-01001A

## About GPS

The Global Positioning System (GPS) is a constellation of satellites that a GPS receiver uses to calculate geographical positions. To determine a position, data from at least three satellites is required. To determine elevation, the data from four or more satellites is required. Accuracy of the positioning varies from 10 feet to several hundred feet, depending on vehicle placement and the surrounding environment.

Geographical terrain (such as mountains), man-made structures (such as highway overpasses, bridges, and tall buildings), as well as weather can interfere with the GPS signal. For best GPS reception, position the device and mount with a clear line of sight to the sky. Some vehicles may have a limited view of the sky due to metal sun shields or a metallized windshield coating.

Map data includes the geographical coordinates for address locations and points of interest (POIs). With GPS reception, your device calculates a route to your selected location.

### Customer Support

**Call toll-free:**

800-333-0136

**Service hours:**

Monday through Friday, 7 a.m. to 6 p.m. CT  
(Except official holidays)

**E-mail:**

RVNDSupport@randmcnally.com

<b>1. Your Device</b>	1	Route to Address/City/Intersection	34-36
Safety Information	1	Address Book	37-38
What's Included	2	Multi-Stop Trips	39-41
Charge the Battery	2	Avoid List	42
Install the Mount	2	Points of Interest (POIs)	43-46
RV Tablet 70 Hardware	3	Local Search	47
		Confirmation Windows	48
		Toll Costs, Route Compare	49
<b>2. Getting Started</b>	6		
Main Menu	6	<b>5. Additional Features</b>	50
Guide to Truck Tools and Device Preferences	7	Wi-Fi	50
Truck Info	8	Weather	51
General Preferences	9-10	Fuel Prices	52
Route Preferences	10	Traffic	53-54
Map Preferences	11		
Warnings	12	<b>5. RV Tools</b>	55
<b>3. RV GPS</b>	10	RV Info	56
Settings	11-14	Status	57
Map Views	15	Mileage	58
Search for an Address	16-17	Trails	59
Search for Points of Interest	18	Fuel Logs	60
Route Map Window	19	Quick Planner	61
View Directions	20-22	RV Level	62
Exits Quick View	23	Road Atlas Information	63
Route to Here, Set Origin	24	Calendar, Notes, Unit Converter, Calculator	64
Add as Via	24-25	Tell Rand	65
Alternate Routes	26		
Junction View	27	<b>6. TripMaker &amp; Atlas</b>	66
Location and Route Options	28	TripMaker	66
Virtual Dashboard	29	Road Atlas	67
Reset Trip Information	30		
Destinations	31	<b>7. Additional Apps</b>	66-70
Tips	32		
New Location	33	<b>8. More Information</b>	71

## Caution: Important Safety Information

### Navigation

- Use this device at your own risk.
- Use this device only when it is safe to do so.
- Look at the display only when it is safe to do so.
- Traffic regulations always have priority over any instructions from the navigation system.
- Follow navigation system instructions only when local regulations and road traffic allow you to do so.
- Make sure that the mount is securely mounted and properly adjusted before each trip.
- **Note:** If you do not understand the spoken instructions or are unsure of what to do next, refer to the navigation map on your navigation device.

### Installation

- Make sure that the mount does not impair the driver's visibility.
- Do not attach the mount within the airbag deployment zone.
- When installing the mount, make sure that it does not pose a risk in the event of an accident.
- Do not run cables directly next to safety-relevant devices and power supplies.
- After installation, check all safety-relevant equipment.
- Connect the wall charger to a 120V or 240V outlet only.
- Connect the vehicle charger to a 12V outlet only.

### Device

- Do not use sharp-edged objects on the device touch screen.
- The device is not waterproof and is not protected against water damage.
- Protect the device from extreme temperatures. Operating temperature for the device is between 32 degrees F and 120 degrees F.
- Do not open the navigation device casing.
- Do not attempt to replace the battery. Contact Rand McNally Customer Support with questions about the battery.
- Always follow local regulations when disposing of this device.
- **Note:** Make sure that there are no kinks in the cable and that it will not be damaged by any sharp objects.
- **Note:** Use only a moist cloth to clean the navigation device.
- **Note:** Do not pull the cable to unplug the unit.

## What's Included

Rand McNally RV Tablet 70

- Two-piece mount:
  - Magnet with GPS boost
  - Bracket with suction cup
- Quick Start Guide
- Anti-glare screen protector
- Vehicle charger
- Wall charger
- USB cable

## Install the Mount

**Note:** Follow all local regulations governing the placement of the mount.

1. Select an area with a line of sight to the sky and GPS satellites.
2. Clean and dry the mounting area.
3. Remove the suction cup protective film.
4. Attach the two pieces of the mount together and lock into place.
5. Adjust the angle of the mount.
6. Pull the suction cup lever up to release suction.
7. Plug the power cord into the mount and the vehicle's 12-volt power source.
8. Place and hold the mount suction cup against the mounting surface.
9. Press the suction cup lever down until it snaps into place.
10. Snap the tablet onto the mount.
11. Adjust the tablet so that it can be easily seen and does not block the driver's line of sight.



## RV Tablet 70 Hardware





### Connecting to Wi-Fi

When you first turn on your tablet, you'll be asked to select a Wi-Fi network to connect to the Internet. A Wi-Fi connection is required to browse the web, download apps, and use Internet-enabled features such as weather and traffic. Choose your wireless access point or hotspot from the list and type in your password.

**Note:** If you skip this step, you will not be able to use all the features of your tablet. The RV GPS app, however, does not require a Wi-Fi connection.


The image shows a tablet screen with a black background. At the top center is the Rand McNally logo, which consists of a blue circle containing a white stylized 'A' with a compass needle. Below the logo, the text 'RAND McNALLY' is displayed in white, with 'RAND' in all caps and 'McNALLY' in title case. Underneath that, the word 'welcome' is written in a light blue, lowercase font. A blue rectangular button with white text 'Set up your RV TABLET' is positioned below the welcome message. At the very bottom of the screen, there are three small, light blue icons: a left-pointing arrow, a house icon, and a document icon.

### Registration


In the next step, you'll be prompted to register your tablet with Rand McNally. Your registration ensures that you have access to the latest information and updates, as well as customer support.



### Using Android




- 1 GPS is on
- 2 Wi-Fi is on
- 3 Indicates remaining battery power
- 4 Current time
- 5 View installed apps
- 6 Tap or swipe right to view second home screen
- 7 Back
- 8 Return to last home screen
- 9 View open apps



### Settings

Swipe down from the right to view quick settings:

- **Brightness**
- **Wi-Fi** – Shows available networks
- **Auto-rotation** – Controls whether the screen rotates when you rotate the tablet
- **Battery power**
- **Airplane mode** – Turns off Wi-Fi and data transmission
- **Bluetooth** – Pairs other devices
- **Location** – Set mode (high accuracy recommended)
- **Screenshot** – Saves an image of the current screen




### All Settings

#### Wireless and Networks

- **Wi-Fi** – View and connect to available Wi-Fi networks.
- **Bluetooth** – Pair with another device using Bluetooth.
- **Data usage** – Monitor how much data has been used by different apps.

#### Device

- **Home** – Select a different launcher. This will change the home screen that appears when the tablet powers on.
- **Sound** – Set volumes for different features and enable/disable sounds.
- **Display** – Set brightness, wallpaper, and appearance.
- **Storage** – View how much internal storage is available on your tablet.
- **Battery** – View time spent on battery and battery power used by different apps.
- **Apps** – View apps. Swipe right to view: downloaded, on SD card, running, all.



### All Settings

#### Personal


- **Location** – View location mode, requests, and reporting. High accuracy mode is recommended.
- **Security** – Enable screen security (each time the screen turns on) and encryption (each time the tablet powers on). Also view passwords, device administration, and credential storage.
- **Language & input** – Set language and keyboard information, as well as speech options and pointer speed.
- **Backup & reset** – Back up the data stored on your tablet.

#### Accounts

- **Add accounts** – Add your email or other accounts.

#### System

- **Date & time** – Set date and time, time zone, and clock format.
- **Accessibility** – Enable spoken feedback to help blind and low-vision users.
- **Printing** – Enable printing services.
- **About tablet** – View network status and version numbers.



- 1 **RV GPS Main Menu** (See page 11.)
- 2 **TripMaker®**  
Use the online planning tool to plan a trip with multiple via points and transfer it to the navigation app as a multi-stop trip. (See help available online.)
- 3 **Road Atlas** (See page 60.)
- 4 **Dash Cam** (See page 61.)
- 5 **Backup Cam** (Requires accessory.)



The bottom three buttons on the home screen can be changed according to your preferences. (To replace with other apps, open the app tray by tapping the upper right corner of the screen. Select **Rand McNally Launcher** and **Home Widget** settings. Tap a box and select a shortcut, or tap applications to view more. Tap **Save**.)



#### Notes on using the RV GPS app:

- When your tablet is attached to the magnetic mount, the GPS boost within the mount will provide accurate GPS location, even without a Wi-Fi connection.
- Weather, traffic, fuel prices, and local search within the RV GPS app require a Wi-Fi connection.
- To exit the RV GPS app at any time, swipe down from the top of the screen or up from the bottom to view the Android menu bars, or tap the main menu button on the front of the device.

Settings

- 1. Tap  and  to view the options.
- 2. Tap the option to be set.
- 3. Enter the new information.

General Preferences	Options
Day/Night Mode	Always day Always night Automatic
RV Info	Tap to open the RV Info screen
Skin Type	Modern Classic
Vehicle Type	RV Car
Screen Click	Click off Click on
Tutorial	View on-device tutorial
Voice Name	Allison Samantha Susan Tom
Language	English (Basic) English (Advanced) Español

General Preferences	Options
	Français <i>For the screen and spoken instructions.</i>
Units	U.S. Standard Metric Auto Select
Toll Prompt/Notification	Enabled Disabled  <i>Set whether or not you want to be asked about tolls when you calculate a route.</i>
Clock Setting	12-Hour Clock 24-Hour Clock
Contact & About	

Route Preferences	Options	Route Preferences	Options
<p><b>Note:</b> The default settings for your device are already optimized for RV routing. Use the options below to fine-tune these settings. A route may still include a roadway or maneuver set to Avoid if the only legal route found contains these types of roads or the route is over several hundred miles.</p>		<b>Tollways</b>	Allow tollways Avoid tollways
<b>Use Traffic</b>	On Off	<b>U-Turns</b>	Allow u-turns Avoid u-turns
<b>Recalculation</b>	Manual recalculate Auto recalculate	<b>Cross-Country Borders</b>	Allow crossing borders Avoid crossing borders
<b>Freeways</b>	Allow all (default) Avoid freeways Prefer freeways Avoid small roads	<b>Dirt Roads</b>	Allow dirt roads Avoid dirt roads
<b>Ferries</b>	Allow ferries Avoid ferries	<b>Manage Avoid List</b>	Roads States/Provinces Areas Routes  <i>To avoid a state or province, select it from this list. Tap on the map and select a road, area, or route to add it to the Avoid List. (See page 31.)</i>
<b>Tunnels</b>	Allow Tunnels Avoid Tunnels	<b>Fast Recalc</b>	Off On <i>Fast recalc calculates a route to a midpoint between your location and the destination, rather than recalculating the entire route from scratch. Best used on a long route that has short distances between intersections.</i>
<b>Turn Announcements</b>	Set three distances at which you want to be warned about an upcoming turn. The first announcement will be the farthest from the turn and the third the closest to it.		
<b>Junction View Distance</b>	Set the distance before the maneuver at which the highway junction view screen appears.		
<b>Route</b>	Fastest route Shortest route		



Map Preferences	Options	Map Preferences	Options
<b>Map Style</b>	Light Dark High contrast	<b>Favorites Icons</b>	Off On
<b>Map Auto Zoom</b>	Off On, auto scale On, street scale On, city scale On, state scale  <i>Set to auto scale to keep the current vehicle position and the next turn in the map view at all times. Set to street/city/state scale to specify the maximum scale of the zoom.</i>  <b>Note:</b> Map redraw speed is impacted by autozoom, especially when combined with 3D map display option.	<i>Favorites entries appear as pushpin icons unless they are assigned to a group. Grouped entries appear as folders.</i>	
<b>Lane Guidance</b>	Off On	<b>Car Icon</b>	Use the arrows to select different icons to display when using the RV setting. Use the slider to change the color.
<b>POI Icons</b>	Off On  <i>Select icons to display on the map.</i>  <i>Select restaurants, banks, and consumer POIs ("Other" category) to display on the map.</i>	<b>RV Icon</b>	Use the arrows to select different icons to display when using the car setting. Use the slider to change the color.
<b>RV POI Icons</b>	Off On  <i>Select parks, campgrounds, pet-friendly locations, and other RV POIs to display on the map.</i>	<b>Map View Mode</b>	Heading Up North Up 3D View
		<b>Route Color</b>	Use the slider to select.


Warnings	Options
<b>Warning/Alert Prompts</b>	None Audio & Visual Visual Audio
<b>Auto Dismiss Warnings</b>	Never After 10 seconds After 30 seconds  <i>Height and weight violations will not be auto dismissed.</i>
<b>Curve Warnings</b>	Set warning distance to curves by using the + and - buttons.
<b>Hill Warnings</b>	Set warning distance to hills by using the + and - buttons.
<b>Narrow Road Warnings</b>	Set warning distance to narrow roads by using the + and - buttons.
<b>State/Province Border Alert</b>	Set warning distance to state borders by using the + and - buttons.
<b>Crossing State Border/ Timezone Change Warning</b>	Off On

Warnings	Options
<b>Toll Booth Alert</b>	Set warning distance to toll booths by using the + and - buttons.
<b>Construction Area</b>	Set warning distance to construction areas by using the + and - buttons.
<b>Speed Limit Warning</b>	Set the amount over the posted limit at which a speed warning appears.  Or set user-defined maximum speed to be warned whenever the vehicle exceeds that speed, regardless of posted speed limits.
<b>Speed Limit Change Warning</b>	Set warning distance to speed limit changes by using the + and - buttons.  <b>Note:</b> To turn warnings off completely, tap the - button until "off" displays.

### Basic Map View




### Expanded Map View



### Main Menu


- 1 **Search For an Address**  
Tap to type in any address or search by keyword.
- 2 **Compass Direction**  
Tap to change the map display. An icon displays the selected option: North up (N), heading up (arrow), or 3D.
- 3 **Zoom In**  
Tap to zoom in.
- 4 **Route Distance**  
Reflects the distance from your point of origin to your destination.
- 5 **Zoom Out**  
Tap to zoom out.
- 6 **Map View Tab**  
Tap to expand the map screen. By default, icons are minimized to show simply the search bar, compass direction, and zoom. Tap again to switch back to the default view.
- 7 **Exit Points of Interest (POI)**  
Tap to view POIs along the exit ahead.
- 8 **Live Data**  
Tap to view fuel, weather, and traffic along the route. (Requires Wi-Fi)
- 9 **Virtual Dashboard**
- 10 **Current Speed**  
Tap to display the Virtual Dashboard.
- 11 **Clock/Elevation**  
Tap to toggle between the clock and elevation.
- 12 **Home (Main Menu)**  
Tap to return to the TND home screen.




### Search For an Address

1. Tap the search bar at the top of the Navigation screen to type in any address or search by keyword. Or, tap any of the categories to search for specific types of destinations.
2. Once a destination is entered, tap **Navigate** and your route options will display.
3. Select either the fastest route or an alternate route.
4. Tap **Start Navigation** to begin the route.

**Note:** If a keyword search does not give the results you need, refer to the Guided Search section beginning in Chapter 4.





## Helpful Tips on Entering Addresses

### Auto-Complete Feature

Enter the first few characters in a name and a short list displays names that start with the typed characters. Continue entering characters until the searched-for name displays in the list. Tap the name to select it.

### Cities




Cities with common names, such as “Athens”, may have multiple locations. The tablet will list all locations. If a name does not display, continue typing characters until the name you are looking for displays in the list.

### State or County Routes

If you’re entering a State or County Route, it’s usually best to first either enter the State or County initials, (for example, State Road 535 would be entered as “SR”) but you may also need to try other options, such as “State Road” or “CA” for California, for example.

### Nearby vs Along Route

You can modify the search to include all areas near your current location by selecting Nearby, or in areas along your current route by selecting Along Route. Tap the Change button to alternate between these searches.



## Points of Interest

You can also use the Map function to search for Points of Interest (POIs) along your route, or near your current location. POIs are organized by categories.

- 1 Tap a POI category in the Search bar.
- 2 Displays POIs nearby, or along your route.
- 3 Tap to view additional POI categories..
- 4 Select a category, and locate a POI from the expanded list.  
**Note:** Turns red when speed limit warning exceeded.  
 (See page 12 to set speed limit alert.)
- 5 Tap the POI.
- 6 Tap **Navigate**, **Add to Favorites**, or **Add as Via**.

**Note:** The **Favorites** icon in the Search bar contains a list of destinations you have added to your Favorites.

## Route Map Window



### 1 Next Maneuver

Tap to repeat spoken next maneuver instructions.

### 2 Road Name

Name of street you will turn onto next.

### 3 Directions Slide-Out List

Tap to select a route display option.

### 4 Compass Direction

Tap to change the map display. An icon in the upper right corner displays the selected option: North up (N), heading up (arrow), or 3D (3). Also displays Wi-Fi status.

### 5 Exits Quick View

Slide out to show upcoming exit information.

### 6 Live Data

Tap to view Traffic, Weather, and Fuel Price Information.

**Note:** This feature requires a Wi-Fi connection.

### 7 Zoom In/Zoom Out

### 8 Map View Tab

Tap to simplify the map screen. Icons are minimized to show simply the zoom, next maneuver, and miles/time.

### 9 Home Screen

### 10 Miles/Time

Displays remaining distance. Tap to select from: yard arrival time, arrival time, remaining time, yard time, and elevation.

### 11 Current Mile Marker

Tap to open a "Tell Rand" message.

### 12 Current Information

View current information by city, street, or upcoming intersection. Also displays advanced lane guidance and weather overlay key, when enabled. Tap to change. (**Note:** For some destinations, the "Am I close?" feature counts down addresses as the vehicle approaches.)

#### City, county, and state

DOWELLTOWN, TENNESSEE

#### Current street name

DAVIS RD

#### Next intersecting street name

VANDERGRIF RD

#### Advanced lane guidance



### 13 Current Speed

Tap to display the Virtual Dashboard. Turns red for speed warnings.

### 14 Virtual Dashboard



### 15 Location and Route Options

Tap to see current location information, change route settings, detour, cancel a route, and manage avoided roads.

### 16 Speed Limit

Orange for RV limit; white for general limit. Tap to open a "Tell Rand" message about speed limits.



**Detail View****Highway View****View Directions****Route Display Options**

When first opened, the slide-out list displays in Detail View showing each maneuver.


Use  and  to view the instructions.

To change the route display, choose Detail View, Highway View, Trip Summary (for multi-stop trips), or Map View (to view the route from start to finish).

- 1 **Distance**  
Displays the distance for each road segment.
- 2 **Street/Road Name**  
Displays the street name you will be on after performing the next maneuver. Tap any item in the list to view it on the map and to detour around it if necessary.
- 3 **Leg**  
Number of the leg (for multi-stop trips) and distance.
- 4 **Highway Name**  
Displays the highway you will be on.




### Highway View



### Trip Summary (for multi-stop trips)





### Summary Map View (entire trip)



### Directions Slide-Out List

#### Route Display Options

1. When first opened, the slide-out list displays in Detail View showing each maneuver.
2. Use  and  to view the instructions.
3. To change the display option, tap the radio button on the bottom of the screen. See Highway View, Trip Summary (for multi-stop trips), and Summary Map View at left.

#### 1 Next Maneuver

Displays the remaining distance until the next maneuver.

#### 2 Distance

Displays the distance for each road segment.

#### 3 Street/Road Name

Displays the street name you will be on after performing the next maneuver. Tap on any item in the list to view it on the map and to detour around it if necessary. (**Note:** For multi-stop trips, highways in each leg are listed, color-coded by segment.)

#### 4 Total Distance and Time

Total distance and time for the entire trip.


#### 5 Leg

Number of the leg and distance.

#### 6 Leg Destination

Leg destination.


## Trip Summary View (for multi-stop trips)




## View Directions Continued

- 1 **Total (or Approximate) Distance and Time**  
Displays the total distance and time for the entire multi-stop trip.
- 2 **Leg**  
Number of the leg (for multi-stop trips) and distance.
- 3 **Destination**  
Destination for that leg of the trip.
- 4 **Remove Stop**  
Tap to remove the stop from the trip.

## Map View (entire route)







#### Exits Quick View

Slide out to show Points of Interest and amenities at upcoming exits. The list displays the distance to the next exit, exit number, and a count of available amenities.

1. Tap an exit to bring up a list of POIs and amenities at that exit.
2. Tap **All**, **Fuel**, **Food**, or **Hotel** to display locations by category.
3. Tap any item in the list to route to that location.






### Route to Here, Set Origin, Add as Via

You can drag the map with your finger to move it to another location. The crosshairs will display when you move the map. Place the crosshairs over the location you are looking for. When you find the location, press and hold the screen for a few seconds and choose **Route to Here**, **Set Origin**, or **Add as Via**.


- 1 **Crosshairs**  
Drag the crosshairs over the desired location.
- 2 **Route to Here**  
Tap **Route to Here** to navigate to the location.
- 3 **Set Origin**  
Tap to set the location as the origin. The origin is the starting point of the route.
- 4 **Save to Favorites**  
Add the location to your Favorites.
- 5 **As as Via**  
Add the location as a via point between the origin and the destination. Use this feature to create multi-stop trips.
- 6 **Avoid or Detour**  
Add the location as a point to avoid on all future routes, and/or to create a detour around the location.
- 7 **Location Icon**  
Shows the distance, in miles, from your current location to the crosshairs on the map. Tap to re-center the map on your current RV location.





### Add as Via (Multi-Stop Trips)

To create a multi-stop trip, you must select and begin navigation to a location. Once the TND begins navigating, select another address (or POI), and select the **Add as Via** option.

- 1 Select **Add as Via**.
- 2 Select where to add the via point to the trip. You can add it to the beginning of the trip, add it to the end of trip, or manually reorder multiple via points by selecting **Reorder Trip**.
- 3 To reorder a trip, select the destination to move up or down in the list.
- 4 Use the arrow buttons to move that destination (destinations order first to last in top to bottom order, respectively).
- 5 Tap **OK** to navigate the newly ordered multi-stop trip..







## Alternate Routes / Avoid Tolls

The TND Map will often select multiple routes to reach your destination. You can choose to navigate to any of the routes offered. The routes will display in different colors on the map.

- 1 Select Add as Via.
- 2 Select which route to use, and tap **Start Navigation**.
- 3 If the selected route contains toll costs, a warning box displays. You can choose:
  - **Use Current Route** to use the current route anyway (incurring tolls)
  - **Compare Routes** to compare alternate routes to select a route without tolls
  - **Don't Prompt for Tolls** to prevent additional toll warnings from displaying



#### Junction View



When on a route, Junction View displays when you have an upcoming maneuver. Set distance in **Preferences > Route**. Once past the maneuver, Junction View closes and the previous window displays.

- ① Signs to follow for the next maneuver.
- ② Number and direction of lanes for the next maneuver.
- ③ Distance to the upcoming maneuver. Distance decreases as you approach the ramp.
- ④ Lane assist arrow.
- ⑤ Return to previous window.



#### Turn View

Displays for upcoming turns. Set distance in **Preferences > Route**.






## Location and Route Options

- 1 Nearest cross street
- 2 Current road you're on, current town you're in
- 3 Latitude and longitude at current location
- 4 Return to previous window
- 5 Detour
- 6 Detour the entire route and add it to the avoid list.

## Around Part of the Route

1. On the left side of the Window, tap the number of miles on the route to be avoided.
2. The route is recalculated.


## Around a Specific Roadway

1. On the right side of the Window, tap  and  to view a list of roads in the current route.
2. Tap on one or more roadways to be avoided. A check mark  appears in front of each selected road.
3. Tap **Detour** to recalculate the route.


**Note:** Tap **Cancel Detour** to remove detours.

- 7 Skip to next stop (for multi-stop trips).
- 8 Cancel current route.
- 9 Save current location to the Favorites.
- 10 Access list of avoided roads.
- 11 Access Route Preferences.
- 12 Access list of temporary avoids/detours.






Tap here



## Virtual Dashboard

To show the Virtual Dashboard, tap the **Current Speed**.

- 1 Current direction of travel.
- 2 Displays current times at the yard, current location and destination, as well as estimated time of arrival.
- 3 Sunrise and sunset times based on vehicle location (latitude/longitude) and day.
- 4 Current speed (above) and posted speed limit (below).  
**Note:** Turns red when speed limit warning exceeded. (See page 12 to set speed limit alert.)
- 5 Elevation at current location.
- 6 Percentage of current trip completed, distance to next maneuver, and the number of miles and time spent on the trip to this point.
- 7 Match with RV's odometer to automatically update new fuel logs.
- 8 Return to the **Route Map Window**.
- 9 Gather trip information for up to three trips. Includes odometer settings, hours, and speeds.
- 10 Reset trip information for the selected trip (**Tab 1**, **Tab 2** or **Tab 3**).
- 11 Select to automatically reset the information in each tab after the vehicle has remained stationary for the specified number of hours.
- 12 View fuel logs and add fuel purchase information.




### Manually Reset Trip Information

1. Tap on the tab you want to reset.
2. To set the odometer for the selected tab back to zero, tap **Reset All**.
3. Information is captured as you travel the route.

### Automatically Reset Trip Information

To reset trip information after the vehicle has remained stationary after a specific number of hours:

1. Tap on the tab you want to reset.
2. Tap **Auto Reset**.
3. Tap **+** to increase the number of hours.
4. Tap **-** to decrease the number of hours.
5. To save changes, tap **Change**.
6. The Tab displays the auto reset number of hours.



## Destinations

To access this window, tap **Guided Search** on the map.

- 1 **Back**  
Tap to return to the map.
- 2 **New Location**  
Tap to route to a new location by address, city center, intersection, or latitude/longitude.
- 3 **History**  
Tap to route to a recently entered location.
- 4 **Favorites**  
Tap to view a list of saved locations.
- 5 **Multi-Stop Trips**  
Tap to view a list of saved multi-stop trips or to create a new one.
- 6 **Points of Interest/POIs**  
Tap to search for a point of interest (POI) such as a gas station, restaurant, etc.
- 7 **Local Search**  
Tap to search for local businesses, restaurants, and more by name or keyword. (**Note:** Wi-Fi connection required.)
- 8 **Rand McNally Trips**  
Tap to select from pre-made Rand McNally routes, including scenic tours, weekend getaways, and more.



Tap to view a longer list of names matching the typed characters.



Add a space.



Delete last character and move back one space.



Type a number, apostrophe, hyphen, or other symbol.

## Helpful Tips on Entering Addresses

### Auto-Complete Feature:

Enter the first few characters in a name and a short list displays a couple of names that start with the typed characters.

On the keyboard, the only keys available are for the next valid characters in a search name.

Continue entering characters until the searched-for name displays in the list. Tap on the name to select it.

### Cities:

Some cities with common names such as "Athens" have several types of names associated with a city.


If a name does not display, continue typing characters until the name you are looking for displays in the list.

### Streets:

If the next letter in the street name can not be selected on the keyboard, tap **Expand Search** to search a greater area.

The **Expand Search** button can also help locate addresses that may actually be in a different town, spelled slightly differently, or in a neighboring town.

**Note:** If you're entering a State or County Route, it's typically best to first either enter the State or County initials (for example, State Road 535 would be entered as "SR") but you may also need to try other options, such as "State Road" or "CA" for California, for example.



## New Location

- 1 Address**  
Tap to route to an address by entering the city, street, and number, or by entering the zip code and street.
- 2 City Center**  
Tap to route to a city center.
- 3 Intersection**  
Tap to route to two intersecting roads in a city.
- 4 Back**  
Tap to return to the previous window.
- 5 Enter Lat/Long**  
Tap to route to a location by latitude and longitude.
- 6 Go To Map**  
Tap to return to the map.



## Search for an Address

1. Tap **Guided Search** > **New Location** > **Address**.
2. Type the first few characters in the city name. As you type, a short list of matching city names displays.
3. Tap on a city to select it.
  - If the city is not displayed on the short name list, continue typing characters in the city name or tap **List** to display a long list of city names. Use the up and down arrows to view all cities/states. Tap on a city to select it.

**Note:** If a city name appears twice within a state, you may need to check both for your specific address.

4. Or tap **Enter Zip Code**. Type the zip code.
5. Type the first few characters in the street name, or if the next characters of the street name cannot be selected on the keyboard, tap **Expand Search** and search a wider area.
6. Tap on the street name from the displayed list.
7. Tap the house number or tap **List** to show a list of address ranges and select a range.

**Note:** To enter the **House Number** before the street, tap this button in step 5. This preference will be saved for subsequent address entry.

8. Tap on the street number range from the list.  
The **Confirmation Window** displays.
9. Tap **Begin New Route** to navigate to the location.





### Route to a City Center

1. Tap **Guided Search** > **New Location** > **City Center**.
2. Type the first few characters in the city name.
3. Tap on the city/state name.  
The **Confirmation Window** displays.
4. Tap **Begin New Route** to navigate to the location.

### Route to an Intersection

5. Tap **Guided Search** > **New Location** > **Intersection**.
6. Type the first few characters in the city name.
7. Tap on the city name.
8. Type the first few characters in the primary street name, or if the next characters of the street name cannot be selected on the keyboard, tap **Expand Search** and search a wider area.
9. Tap on the street name in the list.
10. Type the first few characters in the intersecting street name.
11. Tap on the intersecting street name.  
The **Confirmation Window** displays.
12. Tap **Begin New Route** to navigate to the location.







### Route to a Latitude/Longitude

1. Tap **Guided Search** > **New Location** > **Enter Lat/Long**
2. Tap in the **Latitude** field.
3. Enter the latitude of the location and tap **Enter**.
4. Tap in the **Longitude** field.
5. Enter the longitude of the location and tap **Enter**.
6. Tap **Go**. The **Confirmation Window** displays.
7. Tap **Begin New Route** to navigate to the location.

**Note:** There are two ways to enter latitude/longitude: by decimal degrees or by degrees, minutes, and seconds.





## Favorites

### Add Locations to the Favorites from the Confirmation Window

:


1. Tap **Save to Favorites**.
2. Tap **Yes** to accept the default name or tap **No** to display a keyboard.
3. Type the name of the location and tap **Enter** to save the location in the Favorites. The Confirmation Window re-displays.

## Entries


- Tap **Guided Search > Favorites**. Entries are alphabetically sorted by **Name**.
- To sort by **Distance** or **Date**, tap **Sort By**.
- Use the up and down arrows to scroll through the list or use the alphabet buttons on the left.
- Tap the **Search** field to search the Favorites by keyword.
- The notepad icon indicates a note has been added for this location.

## Route to an Favorites Location

1. Tap **Guided Search > Favorites**.
  - Tap on the **All Addresses** tab or
  - Tap on the **Groups** tab.
2. Tap on an address to select it. The **Confirmation Window** displays.
3. Tap **Begin New Route** to navigate to the location.



### Create a Group

1. Tap **Guided Search** > **Favorites**.
2. Tap on the **Groups** tab.
3. Tap **New Group**.
4. Type the group name.
5. To select a different color folder, tap .
6. Tap on a color, then tap **Close**.
7. When finished, tap **Enter**.

Tap on the **X** next to a group to delete the group.  
Addresses will still be saved in the Favorites.



**Note:** You can also choose to display Favorites icons on the map.

### Add an Address to a Group


1. Tap **Guided Search** > **Favorites**.
2. Tap the **Groups** tab.
3. Tap on the group you want to add an address to.
4. Tap **New Location**.
5. Tap **Enter New Address, History, Favorites, or POI**.
6. If you selected:
  - **History, Saved, or POI**, the selected location is added to the group.
  - Enter a New Address, tap **Yes** to accept the default name or tap **No** to display a keyboard and enter a new name.

### Remove an Address From a Group

1. Tap **Guided Search** > **Favorites**.
2. Tap on the **Group** tab.
3. Tap on the Group you want to remove the address from.
4. Tap on the **X** next to the address to be removed.
5. Tap **Yes**.



### Create a Multi-Stop Trip

1. Tap **Guided Search** > **Multi-Stop Trips**.
2. Tap **New Trip**.
3. Type the trip name.
4. To select a different color folder, tap .
5. Tap on a color, then tap **Close**.
6. When finished, tap **Enter**.

**Note:** A multi-stop trip can include up to 50 stops.

### Add a Stop



**Note:** You can add locations in the order you want to route to them or reorder stops later

From the Main Menu:

1. Tap **Guided Search** > **Multi-Stop Trips**.
2. Tap on the route.
3. Tap **Add Locations**.
4. To add an address, tap **Enter New Address**, **History**, **Favorites**, or **POI**.
5. A Confirmation Window asks if you want to add another stop. Tap:
  - **Yes** to add another stop
  - **No** if the route is complete.
6. Tap **Back** to save changes.

### Remove a Stop

1. Tap **Guided Search** > **Multi-Stop Trips**.
2. Tap on the route.
3. Tap on the **X** next to the stop to be removed.
4. Tap **Yes**.



## Reorder Routes

### Optimize Automatically

After all locations have been added to a multi-stop trip, you can run the optimizer wizard to organize your trip.

1. Tap **Guided Search > Multi-Stop Trips**.
2. Tap on the route you want to optimize.
3. Tap **Reorder Trip**.
4. Tap **Automatic/Optimize**.
5. Tap **Select First Stop** and select the first stop, or **No Preference**.
6. Tap **Select Last Stop** and select the last stop, or **No Preference**.
7. Tap **Yes** to return to your current location to complete the route or **No** to complete the route at the last stop.
8. Tap **Start Trip** to begin the route.

**Note:** There is a limit of ten stops that can be optimized automatically.

### Reorder a Route Manually

1. Tap **Guided Search > Multi-Stop Trips**.
2. Tap on the route you want to optimize.
3. Tap **Reorder Trip**.
4. Tap **Manual**.
5. Tap on the stop to be moved and tap the arrows to move stops up or down.
6. When finished, tap **OK**.
7. Tap **Start Trip** to begin the route.



### Select and Run a Saved Route


1. Tap **Guided Search > Multi-Stop Trips**.
2. Tap on the route to select it.
3. Tap **Start Trip**. The **Confirmation Window** displays.
4. Tap **Begin New Route** to navigate to the location.
5. The TND™ calculates the route to your first stop. When you have reached the stop, a message displays.
6. Tap:
  - **Next Stop** - To calculate a route to the next stop in the route.
  - **Skip Next Stop** - To skip the next stop and calculate a route to the stop after the next one.
  - **End Current Trip** - To end the route at the current stop.

**Note:** To view your entire trip, select **Summary Map View** from the **Route Display Options**.

### Delete a Route

1. Tap **Guided Search > Multi-Stop Trips**. The Multi-Stop Trips window displays.
2. Tap on the **X** next to the route to be deleted.
3. A confirmation message displays.
4. Tap:
  - **Yes** to delete the route.
  - **No** to keep the route.

### Avoid Options



### Avoid Route



### Avoid Area



### Avoid List

From the map, set specific locations to avoid. Tap on the map and select **Permanent Avoid**. Choose **Avoid Route**, **Avoid Road**, or **Avoid Area**. Or, if the location is along an active route, choose **Detour**.

#### Avoid Route

Choose whether to avoid an upcoming distance on an active route, in the left column, or a specific road section, in the right column. Or, select **Avoid Entire Route**. The route is recalculated and the avoided sections are added to the Avoid List, under **Routes**.

#### Avoid Road

Add the selected road segment to the Avoid List, under **Roads**. (**Note:** Reposition the map after zooming in or out to be sure to select the right location.) Road segments that have been permanently avoided are shown in pink on the map when zoomed in. Tap on a segment and tap **Remove Avoid** to remove the segment from the Avoid List.


#### Detour

Detour around a road segment on an active route. The route is recalculated, but the road segment is only avoided temporarily and does not appear on the Avoid List. To cancel the detour, tap the icon in the lower left-hand corner of the map screen and select **Detour**.

#### Avoid Area

Set an area on the map to avoid. Increase/decrease the size of the area using the **+** and **-** buttons. Tap **Save** to add the area to the Avoid List, under **Areas**. Enter a name for the area. If an active route has been entered, the route does not recalculate. Avoided areas are shown on the map in pink.

To remove items from the Avoid List, tap **Manage Avoid List** in **Preferences > Route**. Tap the **X** to remove. Tap **Roads** in the Avoid List to view avoided roads on the map. You may need to re-enter your destination to recalculate an active route.



### Points of Interest (POIs)

- 1 **My RV**  
Tap to search for a point of interest near the current vehicle location.
- 2 **City**  
Tap to search for a point of interest in a city.
- 3 **My Route**  
Tap to search for a point of interest along the vehicle route.
- 4 **Destination**  
Tap to search for a point of interest near the route destination.
- 5 **Back**  
Tap to return to the previous window.
- 6 **Custom POI**  
Tap to select a custom POI location.
- 7 **Quick Stops**  
Tap to find a RV-friendly POI near the current RV location.
- 8 **Go to Map**  
Tap to return to the map.







### Points of Interest (POIs)

- 1 RV Campgrounds**  
Tap to search for a campground with RV amenities.
- 2 RV Services**  
Tap to search for an RV services POI.
- 3 Parking/Rest Areas Border Crossings**  
Tap to search for RV parking, a rest stop, or a border crossing POI.
- 4 Travel Centers**  
Tap to search for a travel center with RV amenities.
- 5 Rand McNally Editor's Picks**  
Tap to search top POIs selected by Rand McNally's travel editors.
- 6 Other Categories**  
Tap to select a consumer (non-RV) related point of interest.
- 7 Back**  
Return to previous window.



## Other Categories

1. Tap **Guided Search** > **Points of Interest**.
2. Select a search type (**My RV/My Car**, **City**, **My Route**, **End of Day**, or **Destination**).
3. Tap **Other Categories**.
4. Tap on a category. (For example, tap **Hospital/Emergency**.)
5. If necessary, tap on a subcategory type. (For example, tap **Pharmacy**.)
6. Tap on a location from the list  
or
7. Tap **All**.
8. Tap on the **Spell** button to display the keyboard.
9. Type the first characters in the POI name.
10. Tap on the POI name in the displayed list.



### Select and Filter Travel Center Amenities and RV Services

RV-related Travel Center points of interest can include over 70 different types of amenities. To select only the travel centers with the amenities that you are interested in, filter your search results.


1. Tap **Guided Search** > **Points of Interest**.
2. Select a search type (**My RV/My Car**, **City**, **My Route**, **End of Day**, or **Destination**).
3. Tap **Travel Center** or **RV Service**.
4. Tap **Select Services**.
5. Click on the check box of each amenity to be included in the search.
6. Tap **OK**.  
The Travel Center window displays POI locations with your selected amenities.
7. Tap on a location from the list.
8. A check next to Filter indicates the search terms have been applied. Tap **Filter** to return to general search results.

### Rate a RV Point of Interest

You can rate RV POIs from the **Confirmation Window**.

For each POI, the top row indicates the community rating from fellow drivers for the point of interest. The bottom row indicates your individual rating.

1. Tap on the **POI Ratings** button.
2. Use **–** and **+** to rate the facility.
3. Tap **Create Comment** and type a personal comment on the facility.
4. Tap **Enter** to save the comment.
5. Tap **Back** to save changes.



**Note:** This feature requires a Wi-Fi connection.

Use Local Search to search the Internet for a restaurant, business, or any type of location by name, keyword, or category. Tap **Guided Search** > **Local Search**.

Choose whether to search:


- 1 near your RV
- 2 in a specific city
- 3 near your destination

Select a category, or tap **Keywords** to search using a specific name (e.g., "Subway") or a keyword ("sandwich").


- 4 Tap **Nearby Food** to show a list of area restaurants based on your current location.
- 5 Tap **My Local History** to show a list of previous searches.

Screens differ according to destination type:


#### New Location



#### RV POI




#### Favorites



### Confirmation Windows

- 1 **Destination Address**  
The selected location address.
  - 2 **Begin New Route**  
Tap to route to destination.
  - 3 **Compare Routes**  
Tap to choose between two routes
  - 4 **Add as Via**  
Add this location as an interim stop between the origin and destination. This automatically makes the current route a multi-stop trip.
  - 5 **Save to Favorites**  
Add the location to the Favorites or add to Favorites group. (See page 18).
- Atlas**
- 6 Cross-reference to printed Rand McNally Motor Carriers' Road Atlas. (Page numbers apply to the most recent Atlas.)
- Go to Map**
- 7 Tap to view this location on a map.
- Set Origin**
- 8 Tap to set the location as the starting point of a route.
- Map Preview**
- 9 Displays a preview of the destination location on the map.
- Details**
- 10 Tap to view phone number and amenities at this location.
- POI Rating**
- 11 Tap to rate or add a comment to this location.
- Edit Entry**
- 12 Rename or edit this entry in the Favorites.
- Note**
- 13 Add a note about this location in the Favorites.
- Back**
- 14 Tap to return to previous window.



## Toll Costs

From the destination confirmation screen, tap **Begin New Route**. If the calculated route includes tolls, a message appears.


- 1 **Use Current Route**  
Show estimated toll costs and continue along the calculated route.
- 2 **Compare Routes**  
Compare the calculated toll route to an alternate route without tolls. (See below.)
- 3 **Don't Prompt for Tolls**  
Use the current route and disable this prompt for subsequent route calculations.

**Note:** You can re-enable this prompt in **Preferences > General**.



## Route Compare

1. From the destination confirmation window, tap **Compare Routes** to calculate and display two routes and choose between them.
2. Choose to ignore tolls and calculate two routes based solely on route preferences, or to calculate a primary route (which may include tolls) and an alternate route without tolls.
3. The top of the screen displays the total distance and time for each route, as well as any estimated toll costs. Zoom in to get a closer look at each route on the map.
4. Tap either button at the top of the screen to select that route. If the route includes tolls, estimated toll cost will display.




### Wi-Fi



For information on setting up a Wi-Fi hotspot through your cellular phone or laptop computer, please visit [www.randmcnally.com/wifihelp](http://www.randmcnally.com/wifihelp) for basic instructions, or contact your wireless carrier.

**Note:** Wi-Fi connectivity requires a supporting feature and data plan from your wireless service provider. As the user, you are responsible for all data charges. Please contact your wireless service provider to make sure you do not exceed the limits of your data plan.

Once you have established a Wi-Fi hotspot:

1. Tap **Wi-Fi** icon  on the home screen. (Also accessible from the Preferences menu.)
2. The device searches for available hotspots.
3. Tap the hotspot you want to connect to.
4. Enter the network password. (**Note:** Many passwords are case sensitive.)
5. A confirmation message displays when a connection is established.





Tap to re-display city, street, or intersection.

### Weather

#### Notes:

- This feature requires a Wi-Fi connection.
- The refresh speed of the weather display is dependent on the connection speed. Weather information is updated every few minutes while Wi-Fi connection is active.
- Weather display depends on active weather patterns and map zoom level.

To view current weather information and the three-day forecast for your location, tap the Live Data icon on the map screen and tap the **Weather** tab.

1 View details for current weather alerts.

2 View weather information at your destination.

**Note:** You can view weather information at any other location by tapping the map and then the Wi-Fi icon and the Weather icon.


3 Select type of weather overlay to display on the map.

4 Select from a variety of weather types:

- No weather (turn off)
- Traffic impact
- Temperature
- Feels like
- Current precipitation intensity and type
- Probability of precipitation
- Forecasted precipitation intensity, type, and clouds
- Forecasted precipitation intensity and type
- Dew point
- Relative humidity
- Wind speed

5 Slide to adjust the transparency of the overlay on the map.

**Note:** Use the slider to readjust for visibility when switching between day and night modes.





### Fuel Prices

**Note:** This feature requires a Wi-Fi connection.

To show fuel prices, tap the Live Data icon on the map screen and tap the **Fuel Prices** tab.

- 1 Displays stations and prices, with distance as the crow flies.
- 2 Check to show the icons and prices on the map screen.
- 3 Sort by distance or price.
- 4 Apply filters for type of fuel and specific brand.
- 5 Check to show fuel prices along the route.



### Traffic

**NOTE:** This feature requires a Wi-Fi connection.

To view current traffic information along your route and near your location:

1. Tap **Live Data > Settings** on the map screen. Tap the Traffic radio button to display the traffic overlay on the map.
2. Tap the Traffic tab.
3. The Traffic tab displays traffic events along your route.
4. Use the **Flow** and **Incidents** checkboxes to view or hide each type of traffic events
5. Tap the **X** to return to the map.
6. Traffic pattern display on the map as colored lines. Traffic Incidents display as icons.

Traffic indicators:

**Green:** Light or no traffic

**Yellow:** Moderate to heavy traffic

**Red:** Slow traffic

**Tap any traffic icon for incident details.**

### Traffic Icons



**Danger**



**Accident**




**Incident**



**Closure**



**HOV Lanes**



**Exit blocked**



**Entrance blocked**



**Traffic**



**Carpool**



**Road work**



**Obstruction**



**Stop Ahead**



**Road condition**



**Temperature**



**Speed Limit Change**



**Wind**



**Activities**



**Security**



**Delay**



**Cancel**



**Travel time**



**Size/weight limit**



**Visibility**




**Heavy traffic**



**Moderate traffic**



**Light traffic**



### RV Tools

RV Tools are located on the second page of the RV Tablet 70. To access this page, swipe right to left on the home screen. Swipe from left to right to return to the Home screen.

Tap the RV Tools icon to access:

**RV Info:** Enter RV information (weight, length, etc.).

**Checklist:** View trip checklists; maintenance records; trails; and fuel purchase information.

**Quick Planner:** Between any two cities or towns, quickly calculate the distance, driving time, and cost.

**Unit Converter:** Quickly convert distance, weight, and temperature.

**Notes:** Add, edit, and manage notes.

**Calculator:** Access a scientific calculator.

**Road Info:** Quickly access contact information for emergency and local regulatory agencies, with information about each state/province/region.

**Tell Rand:** Compose a message to send to Rand McNally.

**RV Level:** Gyroscope tool to help balance your RV.


**RV Trader:** Opens the RV Trader website.

**RV Park Reviews:** View and share reviews of RV parks.

RV Info	Options
<b>RV Type</b>	Class A Class A w/Tag Axle Class B Class C Class C (Super) Fifth Wheel Hybrid Trailer Popup Trailer Toy Hauler Trailer Travel Trailer RV Camper
<b>Routing Style</b>	More Truck like Between Truck and Car More Car like  <b>Note:</b> All routes will take physical/legal restrictions into consideration.
<b>Bottles of Propane</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.
<b>Size of Each Bottle</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.
<b>Number of Trailers</b>	0 1 2
<b>Total Length (RV + Trailers)</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.

RV Info	Options
<b>Weight</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.
<b>Height</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.
<b>Width</b>	Use the + and - buttons or enter a numeric value by tapping the calculator.
<b>Number of axles</b>	Use the + and - buttons.





### Checklists

1. Tap **RV Tools**.
2. Tap **Checklist**.
3. Tap the **Checklists** tab.

To complete a preset checklist:

4. Tap on a checklist to select it.
5. Tap the box next to each task to check it off the list.

Or


To add a new checklist:

4. Tap **Custom Checklist**.
5. Enter the name of the new checklist.
6. Select the new checklist from the list.
7. Tap **Add Item** to add tasks.
8. Tap the box next to each task to check it off the list.
9. Tap Back to save changes.
10. If you have not checked off all the tasks, a warning displays.  
Tap **Cancel** to continue completing tasks, **Uncheck All** to clear all checklist tasks, or **OK** to save changes.
11. The **Checklists** tab redisplay, with the number of completed tasks on the right (for example, 2 of 28).

To delete a checklist or an item from a checklist, tap **X**.

**Note:** If you delete preset checklists and want to restore them, tap **Restore Default**.






### Maintenance

Keep track of maintenance performed on your RV.

1. Tap **RV Tools**.
2. Tap **Checklist**.
3. Tap the **Maintenance** tab.
4. Tap **Add Note** and enter the details.
5. Tap **Back** to save changes.


Tap any note to edit or to change the date.

To delete a note, tap **X** .




### Trails

Use **Trails** to record a “bread-crumbs” path of GPS coordinates where your RV has traveled.

1. Tap **RV Tools**.
2. Tap **Checklist**.
3. Tap the **Trails** tab.
4. To record a trail, tap **New Trail**.
5. To end the trail, tap the Trails icon on the map screen. 
6. The trail is recorded in the Trails tab.
7. Tap on a trail to view details.
8. Tap **Show on Map** to display the trail on the map screen.
9. Tap **Edit Name** to change the name of the trail.
10. Tap **Set Color** to change the color of the trail.

**Note:** The **Trails** feature is also accessible from your Favorites.



### Fuel Logs

1. Tap **RV Tools**.
2. Tap **Checklist**.
3. Tap the **Fuel** tab to view a list of fuel logs by quarter.
4. Tap **Add Fuel** to record the date, location and cost of fuel purchase.
5. Tap on any field to edit.
6. Tap **Save** (**Note:** Fuel economy is calculated automatically.)
7. Once fuel purchases have been entered, tap on a quarter to view the details.
8. You can **View by State** or **View by Month**.
9. Tap the state or month to view fuel purchases.
10. Tap **View All** to see all fuel purchases.

**Quick Planner**

From City 1  
**CHICAGO, IL**

To City 2  
**ENGLEWOOD, FL**

Distance: **1280 mi (approx.)**      Driving Time: **23h 16m**


Cost Per Mile:	Total:	Avg. Speed (MPH)
<b>\$0.55</b>	<b>\$704.00</b>	<b>55</b>

**GO TO MAP**

## Quick Planner

Use this tool to quickly estimate the mileage and time between any two cities or towns.

1. Tap **RV Tools**.
2. Tap **Quick Planner**.  
The revenue or cost per mile used in the last computation displays.
3. Tap **From City 1** and select the city.
4. Tap **To City 2** and select the city.
5. The distance displays.
6. Tap **Cost per Mile** and enter the per mile rate or tap **Total** and enter the total amount.
7. Tap the new dollar amount and tap **Enter**.
8. The dollar amounts readjust automatically.
9. Tap **Average Speed (MPH)** enter a speed:
  - Tap -- or + to decrease or increase the speed.
  - Tap the calculator to enter a speed.
10. Tap **Change**.
11. The driving time displays.




### RV Level

You can use the built-in gyroscope in the RV tablet to level your RV after parking.

1. Tap **RV Tools**.
2. Tap **RV Level**.
3. Place your tablet on a flat surface inside the RV.
4. Use the stabilizers to level the RV.
5. When a side is level, a green check displays.
6. Tap **Freeze** to stop the level markers from moving.
7. Tap **Calibrate** to calibrate the level.


**Note:** When calibrating the level, be sure to place the tablet on a surface that you know is already level..



### Road Atlas Information

To reference the Rand McNally *Road Atlas*:

1. Tap **RV Tools**.
2. Tap **Road Info**.
3. Select the appropriate country tab.
4. Select the appropriate state/province to view emergency and other key phone numbers.




### Calendar

1. Tap **RV Tools**.
2. Tap **Calendar**.
3. Use the arrows to view other months and years.
4. Tap **Today** to return to the current date.

### Notepad

1. Tap **RV Tools**.
2. Tap **Notepad**.
3. Tap **New Note**.
4. Tap a note in the list to view and edit.





### Unit Converter

5. Tap **RV Tools**.
6. Tap **Converter**.
7. Tap on the first field and select the type of conversion to perform.
8. Tap on the second field and enter the value to be converted.
9. Tap **Enter**.

### Calculator

1. Tap **RV Tools**.
2. Tap **Calculator**.






## Tell Rand

Enter messages for Rand McNally regarding construction, RV restrictions, addresses, your device, and more.

1. Tap **RV Tools**.
2. Tap **Tell Rand**. On the left side, tap **Current Location**. Enter **Different Location** or **Find Location on Map**.  
**Note:** You can open a Tell Rand speed limit message by tapping the speed limit or mile marker on the map screen.
3. If you selected Enter Different Location, enter it as an address. If you selected Find Location on Map, tap on the map to set the crosshairs at that location, then tap **Back**.
4. On the right side, tap the type of message you want to send.
5. Type your message.
6. Tap **Enter** to save the message.
7. To discard the message and return to the previous window, tap **Back**.
8. To send the message, be sure your device is connected to the Internet.





TripMaker is a trip planning app that allows you to easily browse the map and set up a multi-stop trip. Add via points and send your trip to the GPS app for routing. To access TripMaker, tap the TripMaker icon on the Home screen.

### To create a trip:

1. Enter the starting and ending point for your trip.
2. Choose a name for it.
3. Tap **Create Trip**.


Refer to the help section in TripMaker for more information.





A digital version of Rand McNally's *Road Atlas*.

Tap **Atlas Maps** at the top right to select pages by state.



### Dash Cam

Records a video loop as you drive. Tap the red button to record again to stop.

Tap the menu icon at the top right to access preferences for video quality, audio, and segments.

## 7. Additional Apps

---

Your RV Tablet 70 comes preloaded with apps available from our partners. For support, view help within each app.



RV Park Reviews



RV Spot



RV Trader

## 7. Additional Apps

---

Additional apps are available for download in the Rand McNally Market.  
Look for these complimentary apps:

- **Backup cam** (requires accessory)
- **Rand McNally Motor Carriers' Road Atlas**

Register to receive information and updates from Rand McNally.



Rand McNally Market

### For more information

- Rand McNally Website  
[www.randmcnally.com/rvgps](http://www.randmcnally.com/rvgps)
- Support  
[www.randmcnally.com/support](http://www.randmcnally.com/support)
- GPS accessories  
[store.randmcnally.com](http://store.randmcnally.com)
- Facebook  
[www.facebook.com/randmcnally](http://www.facebook.com/randmcnally)

## **Trademarks**

Rand McNally and the Rand McNally logo are registered trademarks of RM Acquisition LLC, d/b/a Rand McNally.

The RVer's Friend is a registered trademark of TR Information Publishers.

Good Sam is a registered trademark of Good Sam Enterprises, LLC.

Wi-Fi is a registered trademark of the Wi-Fi Alliance.

InfoGation is a registered trademark of InfoGation Corporation.

Local search information provided by CityGrid Media.

Weather data provided by myweather.com.

Fuel prices provided by OPIS.

Traffic information provided by INRIX, Inc.

© 2017 Rand McNally. © 2017 HERE. All rights reserved.

Rand McNally follows a continuous improvement process and reserves the right to provide enhancements that may not be reflected in the pictures and specifications in this manual.

The information contained herein may be changed at any time without prior notification. Neither this manual nor any parts thereof may be reproduced for any purpose whatsoever without the express written consent of Rand McNally, Inc., nor may it be transmitted in any form either electronically or mechanically, including photocopying, and recording. All technical specifications, drawings, etc. are subject to copyright law.



